



Disassemble, Disconnect and Recycle Tron 60S/ Tron 60GPS



Press a screwdriver within the equator belt hatch




About to be opened



Disconnect battery (4 connectors)



Use screwdriver to flip loose electronic



Loose



Tear off coil (Yellow outline)
(Makes the electronics unusable)

Recycle the different parts:

	Part	How	Note
1	Battery	Do NOT throw in waste bin, but recycle as "Haz.mat" (Dangerous goods). - Europe: According to Directive 2006/66/EC - USA: The Big Green box	Contains high energy Lithium Metal batteries of type Energizer L91, see MSDS/PSDS here .
2	Electronics	Do NOT throw in waste bin, but recycled according to legal procedures regarding waste electronic: - Europe: WEEE – see more info: 1) http://ec.europa.eu/environment/waste/weee/index_en.htm 2) http://erp-recycling.org/ - USA: http://www.epa.gov/epawaste/conservation/materials/recycling/index.htm	May contain: <ul style="list-style-type: none"> • Lead (Pb) • Copper(Cu) • Tin (Sn) • Other metals
3	Plastic	Contains mostly Polycarbonate (Lexan) , see information on plastic recycling here: http://en.wikipedia.org/wiki/Plastic_recycling	