

EMERGENCY EQUIPMENT LOCKER STROPS

ADULT SKU - 50040025 CHILD SKU - 50040024

ADULT & CHILD LOCKER STROPS

Manufacturing specification

- ◆ 1800 kg Terylene webbing (breaking strain 3000kg)
- ◆ Welded stainless steel D Rings (breaking load 2750kg)
- ◆ 6mm closed cell foam padding
- ◆ High visibility orange cover

Features

- ◆ Recommended Safe Working Load 150kg
- ◆ Available in both Adult and Child versions
- ◆ Originally Type Approved for use in Ro-Ro Emergency Equipment Lockers.



Using the Adult & Child Locker Stropps

1. With the woggle extended pass the strop over the head, or round the legs of the casualty. Ensure the wide padded part of the strop is as high as possible across the back, with the two straps coming under the armpits and up in front of the face

2. Draw the woggle down as far as possible to close the strop around the chest

3. Keep arms down



4. When ready to be lifted, look up and signal to the rescuers by raising one arm with a 'thumbs up' signal. (If a rescuer is in the water assisting they will make this signal)

5. Put both arms down as described in 3. above

6. Do nothing when hoisted to the rescue vessel until instructed by the crew